

```

1 using static RabbitMQ_SendClient.General_Classes.ModbusConfig;
2 using static RabbitMQ_SendClient.GlobalRabbitMqServerFunctions;
3 using static RabbitMQ_SendClient.GlobalSerialFunctions;
4 using static RabbitMQ_SendClient.SystemVariables;
5
6 namespace RabbitMQ_SendClient
7 {
8     using System;
9     using System.Collections.Generic;
10    using System.Collections.ObjectModel;
11    using System.ComponentModel;
12    using System.Data;
13    using System.Data.SqlClient;
14    using System.Diagnostics;
15    using System.IO;
16    using System.IO.Ports;
17    using System.Linq;
18    using System.Text;
19    using System.Threading;
20    using System.Windows;
21    using System.Windows.Controls;
22    using System.Windows.Controls.DataVisualization.Charting;
23    using System.Windows.Forms;
24    using System.Windows.Media.Animation;
25    using System.Windows.Threading;
26    using EasyModbus.Exceptions;
27    using Newtonsoft.Json;
28    using RabbitMQ.Client;
29    using RabbitMQ.Client.Exceptions;
30    using UI;
31    using CheckBox = System.Windows.Controls.CheckBox;
32    using MessageBox = System.Windows.Forms.MessageBox;
33
34    /// <summary>
35    /// Main UI for RabbitMQ Client
36    /// </summary>
37    public partial class MainWindow : IDisposable
38    {
39        /// <summary>
40        /// RabbitMQ Server Information for setup
41        /// </summary>
42        protected internal static readonly ObservableCollection<CheckListItem>
43            AvailableModbusSerialPorts =
44            new ObservableCollection<CheckListItem>();
45
46        protected internal static readonly ObservableCollection<CheckListItem> AvailableSerialPorts =
47            new ObservableCollection<CheckListItem>();
48
49        internal static ObservableCollection<MessageDataHistory>[] MessagesSentDataPair =
50            new ObservableCollection<MessageDataHistory>[0];
51
52        protected internal static ModbusControl[] ModbusControls = new ModbusControl[0];
53
54        private static readonly StackTrace StackTracing = new StackTrace();
55
56        private static readonly string DatabaseLoc =
57            AppDomain.CurrentDomain.BaseDirectory + "Database\\MessageData.mdf";
58
59        internal static double[] MessagesPerSecond = new double[0];

```

```

60     private readonly string _connString =
61         $"Data Source=(LocalDB)\MSSQLLocalDB;AttachDbFilename=\"{DatabaseLoc}\";Integrated
        Security=True";
62
63     private readonly Dictionary<DispatcherTimer, Guid> _modbusTimerId = new
        Dictionary<DispatcherTimer, Guid>();
64
65     private readonly DateTime _previousTime = new DateTime();
66     private readonly DispatcherTimer _systemTimer = new DispatcherTimer();
67
68     /// <summary>
69     /// Mainline Executable to the RabbitMQ Client
70     /// </summary>
71     public MainWindow()
72     {
73         InitializeSerialPortCheckBoxes();
74         InitializeComponent();
75
76         GetFriendlyDeviceNames();
77
78         InitializeSerialPorts();
79         InitializeHeartBeatTimer();
80
81         _systemTimer.Start();
82     }
83
84     public static LineSeries[] Lineseries { get; set; } = new LineSeries[0];
85
86     public static string DeviceName { get; } = Environment.MachineName;
87
88     /// <summary>
89     /// Close all open channels and serial ports before system closing
90     /// </summary>
91     public void Dispose()
92     {
93         for (var i = 0; i < SerialPort.GetPortNames().Length; i++)
94         {
95             while (SerialPorts[i].IsOpen)
96             {
97                 SerialPorts[i].Close();
98             }
99             SerialPorts[i].Dispose();
100             CloseSerialPortUnexpectedly(i);
101         }
102
103         //Disposes of timer in a threadsafe manner
104         if (_systemTimer.IsEnabled)
105             _systemTimer.Stop();
106     }
107
108     private void GetFriendlyDeviceNames()
109     {
110         var loaded = GenerateFriendlies();
111
112         if (!loaded)
113         {
114             MessageBox.Show(
115                 Properties.Resources.MainWindow_MainWindow_FatalError_ConfigurationFile,
116                 @"Fatal Error - Configuration Failure", MessageBoxButton.OK,
                 MessageBoxIcon.Error);

```

```

117         CloseSafely();
118         Close();
119     }
120 }
121
122 /// <summary>
123 /// Publishes Message to RabbitMQ
124 /// </summary>
125 /// <param name="message">
126 /// JSON/Plain-Text Message. HAS TO BE PREFORMATTED for Json Serialization
127 /// </param>
128 /// <param name="index">
129 /// Index for Dynamic Server Allocation
130 /// </param>
131 /// <param name="uidGuid">
132 /// </param>
133 /// <returns>
134 /// Message success state
135 /// </returns>
136 private bool PublishMessage(string message, int index, Guid uidGuid)
137 {
138     try
139     {
140         var properties = FactoryChannel[index].CreateBasicProperties();
141         if (SerialCommunications[index].MessageType == "JSON")
142             try
143             {
144                 CalculateNpChart(index);
145                 JsonConvert.DeserializeObject<Messages[]>(message);
146                 properties.ContentType = "jsonObject";
147             }
148             catch (JsonException ex)
149             {
150                 if (OutOfControl(index))
151                 {
152                     var sf = StackTracing.GetFrame(0);
153                     LogError(ex, LogLevel.Critical, sf);
154                     CloseSerialPortUnexpectedly(index);
155                 }
156             }
157         else
158             properties.ContentType = "plain-text";
159
160         properties.Persistent = true;
161
162         var address = new PublicationAddress(ExchangeType.Direct,
163             ServerInformation[index].ExchangeName, "");
164         FactoryChannel[index].BasicPublish(address, properties, Encoding.UTF8.GetBytes
165             (message));
166         FactoryChannel[index].BasicAcks += (sender, args) =>
167         {
168             const string sqlString = "DELETE FROM[dbo].[MessageData] WHERE [DeliveryTag] =
169                 @uuid";
170
171             using (var conn = new SqlConnection(_connString))
172             {
173                 try
174                 {
175                     var command = new SqlCommand(sqlString, conn) { CommandType =
176                         CommandType.Text };

```

```
174         command.Parameters.AddWithValue("@uuid", uidGuid);
175         conn.Open();
176         command.ExecuteNonQuery();
177         conn.Close();
178     }
179     catch (Exception ex)
180     {
181         if (conn.State == ConnectionState.Open)
182             conn.Close();
183         var sf = StackTracing.GetFrame(0);
184         LogError(ex, LogLevel.Critical, sf);
185     }
186 }
187 };
188 return true;
189 }
190 catch (AlreadyClosedException ex)
191 {
192     var indexOf = ex.Message.IndexOf("\"", StringComparison.Ordinal);
193     var indexOff = ex.Message.IndexOf("\"", indexOf + 1, StringComparison.Ordinal);
194     var errmessage = ex.Message.Substring(indexOf + 1, indexOff - indexOf - 1);
195     MessageBox.Show(errmessage, @"Connection Already Closed", MessageBoxButton.OK,
196         MessageBoxIcon.Asterisk);
197
198     return false;
199 }
200 catch (Exception ex)
201 {
202     //Log Message
203     var sf = StackTracing.GetFrame(0);
204     LogError(ex, LogLevel.Critical, sf);
205     return false;
206 }
207 }
208
209 private void CloseSafely()
210 {
211     TabMessageSettings.IsEnabled = false;
212     _systemTimer.Stop();
213
214     foreach (var port in SerialPorts)
215     {
216         while (port.IsOpen)
217         {
218             port.Close();
219         }
220     }
221
222     foreach (var model in FactoryChannel)
223     {
224         while (model.IsOpen)
225         {
226             model.Close();
227         }
228     }
229 }
230
231 /// <summary>
232 /// Serial Commnuication Event Handler.
233 /// </summary>
```

```

234     /// <param name="sender">
235     /// COM Port Data Receveived Object
236     /// </param>
237     /// <param name="e">
238     /// Data Received
239     /// </param>
240     private void DataReceivedHandler(object sender, SerialDataReceivedEventArgs e)
241     {
242         try
243         {
244             var sp = (SerialPort)sender;
245             var spdata = sp.ReadLine();
246
247             var i = AvailableSerialPorts.TakeWhile(serialPort => serialPort.Content != sp.PortName).Count();
248             var index = GetIndex<SerialCommunication>(Guid.Parse(AvailableSerialPorts[i].Uid));
249
250             SerialCommunications[index].TotalInformationReceived++;
251             CalculateNpChart(index);
252
253             ProtectData(Guid.Parse(AvailableSerialPorts[index].Uid), spdata, sp.PortName);
254
255             while (!PublishMessage(spdata, index, Guid.Parse(AvailableSerialPorts[i].Uid)))
256             {
257                 //Retry
258             }
259         }
260         catch (Exception ex)
261         {
262             //Log Message
263             var sf = StackTracing.GetFrame(0);
264             LogError(ex, LogLevel.Critical, sf);
265         }
266     }
267
268     private void ProtectData(Guid uidGuid, string message, string deviceName)
269     {
270         var index = GetIndex<RabbitServerInformation>(uidGuid);
271
272         var datInfo = new DataBaseInfo
273         {
274             Message = message,
275             Timestamp = DateTime.Now,
276             FriendlyName = FriendlyName[index],
277             Channel = ServerInformation[index].ChannelName,
278             Exchange = ServerInformation[index].ExchangeName,
279             ServerAddress = ServerInformation[index].ServerAddress.ToString(),
280             DeliveryTag = Guid.NewGuid(),
281             DeviceType = deviceName
282         };
283
284         const string sqlString =
285             "INSERT [dbo].[MessageData]
286             (Message,Timestamp,FriendlyName,Channel,Exchange,ServerAddress,DeliveryTag,DeviceType)VALUES"
287             +
288             "(@message,@timestamp,@friendlyname,@channel,@exchange,@serveraddress,@deliverytag,@devicetype)";
289         using (var conn = new SqlConnection(_connString))

```

```

290         {
291             var command = new SqlCommand(sqlString, conn)
292             {
293                 CommandType = CommandType.Text
294             };
295             command.Parameters.AddWithValue("@message", datInfo.Message);
296             command.Parameters.AddWithValue("@timestamp", datInfo.TimeStamp);
297             command.Parameters.AddWithValue("@friendlyname", datInfo.FriendlyName);
298             command.Parameters.AddWithValue("@channel", datInfo.Channel);
299             command.Parameters.AddWithValue("@exchange", datInfo.Exchange);
300             command.Parameters.AddWithValue("@serveraddress", datInfo.ServerAddress);
301             command.Parameters.AddWithValue("@deliverytag", datInfo.DeliveryTag);
302             command.Parameters.AddWithValue("@devicetype", datInfo.DeviceType);
303             conn.Open();
304             command.ExecuteNonQuery();
305             conn.Close();
306         }
307     }
308
309     /// <summary>
310     /// RabbitMQ Heartbeat Timer. Adjusts value of system information in scrollbar on tick
311     /// </summary>
312     private void InitializeHeartBeatTimer()
313     {
314         try
315         {
316             _systemTimer.Tick += SystemTimerOnTick;
317             _systemTimer.Interval = TimeSpan.FromMilliseconds(100);
318         }
319         catch (Exception e)
320         {
321             var message = e.Message + "\nError in Timer Initialization";
322             MessageBox.Show(message, e.Source, MessageBoxButton.OK, MessageBoxIcon.Error);
323         }
324     }
325
326     /// <summary>
327     /// Initializes SerialPort checkboxes for both Serial and ModBus communication
328     /// </summary>
329     private static void InitializeSerialPortCheckBoxes()
330     {
331         AvailableSerialPorts.Clear();
332         AvailableModbusSerialPorts.Clear();
333
334         var ports = SerialPort.GetPortNames();
335         foreach (var t in ports)
336         {
337             var serialPortCheck = new CheckListItem
338             {
339                 Content = t,
340                 IsChecked = false,
341                 Name = t + "Serial",
342                 Uid = Guid.NewGuid().ToString()
343             };
344             AvailableSerialPorts.Add(serialPortCheck);
345
346             var serialModbusCheck = new CheckListItem
347             {
348                 Content = t,
349                 IsChecked = false,

```

```
350         Name = t + "Modbus",
351         Uid = Guid.NewGuid().ToString()
352     };
353     AvailableModbusSerialPorts.Add(serialModbusCheck);
354 }
355 }
356
357 /// <summary>
358 /// Provides initializing access to the serial ports
359 /// </summary>
360 private void InitializeSerialPorts()
361 {
362     var ports = SerialPort.GetPortNames();
363     if (ports.Length == 0)
364     {
365         LstSerial.Items.Add("No Ports Available");
366         LstModbusSerial.Items.Add("No Ports Available");
367     }
368     else
369     {
370         try
371         {
372             LstSerial.ItemsSource = AvailableSerialPorts;
373             LstModbusSerial.ItemsSource = AvailableModbusSerialPorts;
374         }
375         catch (Exception e)
376         {
377             var message = e.Message + "\nError in Port Enumeration";
378             MessageBox.Show(message, e.Source, MessageBoxButton.OK, MessageBoxIcon.Error);
379         }
380     }
381 }
382
383 /// <summary>
384 /// Provides the required closing processes. Allows for safe shutdown of the program
385 /// </summary>
386 /// <param name="sender">
387 /// </param>
388 /// <param name="e">
389 /// </param>
390 private void MainWindow_OnClosing(object sender, CancelEventArgs e)
391 {
392     foreach (var serialPort in SerialPorts)
393     {
394         if (serialPort.IsOpen)
395             serialPort.Close();
396     }
397
398     foreach (var model in FactoryChannel)
399     {
400         while (model != null && model.IsOpen)
401         {
402             model.Close();
403         }
404     }
405 }
406
407 private void MainWindow_OnLoaded(object sender, RoutedEventArgs e)
408 {
409     var doubleAnimation = new DoubleAnimation
```

```
410         {
411             From = -tbmarquee.ActualWidth,
412             To = canMain.ActualWidth,
413             RepeatBehavior = RepeatBehavior.Forever,
414             Duration = new Duration(TimeSpan.Parse("0:0:10"))
415         };
416         tbmarquee.BeginAnimation(Canvas.LeftProperty, doubleAnimation);
417         doubleAnimation.BeginAnimation(Canvas.LeftProperty, doubleAnimation);
418     }
419
420     /// <summary>
421     /// TODO allow for dynamic updates of serial ports in serial port selection while keeping
422     /// current states
423     /// </summary>
424     private static void ResizeSerialSelection()
425     {
426         var ports = SerialPort.GetPortNames();
427         for (var i = 0; i < ports.Length; i++)
428         {
429             var portName = ports[i];
430             if (portName == AvailableSerialPorts[i].Content)
431             {
432             }
433         }
434     }
435
436     /// <summary>
437     /// Clears relevant modbus related serial port and enables serial port
438     /// </summary>
439     /// <param name="sender">
440     /// </param>
441     /// <param name="e">
442     /// </param>
443     private void SerialEnabled_CheckboxChecked(object sender, RoutedEventArgs e)
444     {
445         if (!this.IsInitialized) return;
446
447         var cb = (CheckBox)sender;
448         var uidGuid = Guid.Parse(cb.Uid);
449
450         var index = GetIndex<CheckListItem>(uidGuid);
451
452         var cbo = (CheckListItem)LstModbusSerial.Items[index];
453         if (cb.IsChecked != null) cbo.IsChecked = false;
454
455         //disables Modbus COM Port
456         AvailableModbusSerialPorts.RemoveAt(index);
457         AvailableModbusSerialPorts.Insert(index, cbo);
458
459         //Enable Port for serial communications
460         SetupSerial(uidGuid);
461         ResizeLineSeries(AvailableSerialPorts[index].Name);
462
463         var setupSerialForm = new SerialPortSetup(uidGuid);
464         var activate = setupSerialForm.ShowDialog(); //Confirm Settings
465
466         switch (activate)
467         {
468             case true:
469
```



```

470     var friendlyNameForm = new VariableConfigure(uidGuid);
471     var nameSet = friendlyNameForm.ShowDialog();
472     if ((nameSet != null) && !nameSet.Value)
473         goto case null;
474
475     SetupFactory(uidGuid);
476     ServerInformation[ServerInformation.Length - 1] = SetDefaultSettings(uidGuid);
477
478     var configureServer = new SetupServer(uidGuid);
479     var serverConfigured = configureServer.ShowDialog();
480
481     if ((serverConfigured != null) && !serverConfigured.Value)
482     {
483         //Canceled
484         Array.Resize(ref ServerInformation, ServerInformation.Length - 1);
485         goto case null;
486     }
487
488     SerialPorts[SerialPorts.Length - 1].DataReceived += DataReceivedHandler;
489     var init = SerialPortInitialize(SerialPorts.Length - 1, this.IsInitialized);
490     tbmarquee.Text += $"Serial Port {cb.Name} Active";
491     if (init) return;
492
493     //Initialization of port failed. Closing port and unchecking it
494     cb.IsChecked = false;
495     AvailableSerialPorts.RemoveAt(index);
496     var cliT = new CheckListItem
497     {
498         Name = cb.Name,
499         Uid = cb.Uid,
500         Content = cbo.Content,
501         IsChecked = false
502     };
503     AvailableSerialPorts.Insert(index, cliT);
504     tbmarquee.Text.Replace($"Serial Port {cb.Name} Active", "");
505     break;
506
507 case null:
508 default: //incl case false
509     cb.IsChecked = false;
510     AvailableSerialPorts.RemoveAt(index);
511     var cliF = new CheckListItem
512     {
513         Name = cb.Name,
514         Uid = cb.Uid,
515         Content = cbo.Content,
516         IsChecked = false
517     };
518     AvailableSerialPorts.Insert(index, cliF);
519     Array.Resize(ref SerialPorts, SerialPorts.Length - 1); //Removes last
        initialization of Serial Port
520     break;
521     }
522 }
523
524 private void SerialEnabled_CheckboxUnchecked(object sender, RoutedEventArgs e)
525 {
526     if (!this.IsInitialized) return;
527
528     var cb = (CheckBox)sender;

```

```

529         var port = SerialPorts.FirstOrDefault(sp => sp.PortName == cb.Content.ToString());
530
531         if ((port != null) && port.IsOpen)
532             port.Close();
533     }
534
535     /// <summary>
536     /// Clears related Serial Port that is not
537     /// </summary>
538     /// <param name="sender">
539     /// </param>
540     /// <param name="e">
541     /// </param>
542     private void SerialModbusEnabled_CheckboxChecked(object sender, RoutedEventArgs e)
543     {
544         if (!this.IsInitialized) return;
545
546         var cb = (CheckBox)sender;
547         var uidGuid = Guid.Parse(cb.Uid);
548
549         var index = GetIndex<CheckListItem>(uidGuid);
550
551         cb.Name = AvailableModbusSerialPorts[index].Name;
552
553         var cbo = (CheckListItem)LstSerial.Items[index];
554         if (cb.IsChecked != null) cbo.IsChecked = false;
555
556         //disables Modbus COM Port
557         AvailableSerialPorts.RemoveAt(index);
558         AvailableSerialPorts.Insert(index, cbo);
559
560         switch (true)
561         {
562             case true:
563                 //Enable Port
564                 SetupModbusSerial(uidGuid);
565
566                 var setupSerialForm = new SerialPortSetup(uidGuid);
567                 setupSerialForm.cboMessageType.SelectedIndex = 1;
568                 var activate = setupSerialForm.ShowDialog();
569
570                 if ((activate == null) || !activate.Value)
571                 {
572                     CloseModbusSerial(uidGuid);
573                     RemoveAtIndex<SerialCommunication>(SerialCommunications.Length - 1,
574                         SerialCommunications);
575                     ResetCheckBox(AvailableModbusSerialPorts[index]);
576                     return;
577                 }
578
579                 index = SerialCommunications.Length - 1;
580                 SerialCommunications[index].X(SerialCommunications[index].MaximumErrors);
581
582                 var port = new SerialPort
583                 {
584                     PortName = SerialCommunications[index].ComPort,
585                     BaudRate = (int)SerialCommunications[index].BaudRate,
586                     Parity = SerialCommunications[index].SerialParity,
587                     StopBits = SerialCommunications[index].SerialStopBits,
588                     DataBits = SerialCommunications[index].SerialBits,

```

```

588         Handshake = SerialCommunications[index].FlowControl,
589         RtsEnable = SerialCommunications[index].RtsEnable,
590         ReadTimeout = SerialCommunications[index].ReadTimeout
591     };
592
593     Array.Resize(ref ModbusControls, ModbusControls.Length + 1);
594     ModbusControls[ModbusControls.Length - 1].UidGuid = uidGuid;
595
596     ModbusControls[ModbusControls.Length - 1].ModbusTimers = new DispatcherTimer
597     {
598         Interval = TimeSpan.FromMilliseconds(1000),
599         IsEnabled = false
600     };
601     ModbusControls[ModbusControls.Length - 1].ModbusTimers.Tick += ModbusTimerOnTick;
602     _modbusTimerId.Add(ModbusControls[ModbusControls.Length - 1].ModbusTimers,
        uidGuid);
603
604     ModbusControls[ModbusControls.Length - 1].ModbusAddressList =
605         new List<Tuple<bool, bool, bool, bool, int>>();
606     index = GetIndex<CheckListItem>(uidGuid);
607
608     var modbusSelection = new ModbusSelection
609     {
610         DeviceAddress = port.PortName,
611         DeviceName = AvailableModbusSerialPorts[index].Name,
612         IsAbsolute = true
613     };
614
615     var addressesInitialized = modbusSelection.ShowDialog();
616
617     if ((addressesInitialized == null) || !addressesInitialized.Value)
618     {
619         MessageBox.Show(@"Failed to create Modbus Configuration", @"ERROR",
        MessageBoxButtons.OK,
        MessageBoxIcon.Error);
        goto case false;
620     }
621
622     SetupFactory(uidGuid);
623
624     var configureServer = new SetupServer(uidGuid);
625     var serverConfigured = configureServer.ShowDialog();
626
627     if ((serverConfigured != null) && !serverConfigured.Value)
628     {
629         Array.Resize(ref ServerInformation, ServerInformation.Length - 1);
630         Array.Resize(ref ModbusControls, ModbusControls.Length - 1);
631         MessageBox.Show(@"Failed to open RabbitMQ Connection", @"ERROR",
        MessageBoxButtons.OK,
        MessageBoxIcon.Error);
        break;
632     }
633
634     InitializeModbusClient(port);
635     tbmarquee.Text += $"Serial Port {cb.Name} Active";
636
637     if (ModbusClients[ModbusClients.Length - 1].Connected)
638     {
639         ResizeLineSeries(cb.Name);
640         ModbusControls[ModbusControls.Length - 1].ModbusTimers.IsEnabled = true;
641         InitializeRead(uidGuid);

```

```

645         break;
646     }
647     MessageBox.Show(@"Failed to open Serial Port", @"ERROR", MessageBoxButton.OK,
648         MessageBoxIcon.Error);
649     goto case false; //unsuccessful
650
651     case false:
652         cb.IsChecked = false;
653         AvailableModbusSerialPorts.RemoveAt(index);
654         RemoveAtIndex<RabbitServerInformation>(ServerInformation.Length - 1,
655             ServerInformation);
656
657         var cliT = new CheckListItem
658         {
659             Name = cb.Name,
660             Uid = cb.Uid,
661             Content = cbo.Content,
662             IsChecked = false
663         };
664         AvailableModbusSerialPorts.Insert(index, cliT);
665         tbmarquee.Text.Replace($"Serial Port {cb.Name} Active", "");
666         break;
667     }
668 }
669
670 private void InitializeRead(Guid uidGuid)
671 {
672     var index = ModbusControls.Select((val, ind) =>
673         new { ind, val })
674         .First(e => e.val.UidGuid == uidGuid)
675         .ind;
676     var modbusItem = ModbusControls.FirstOrDefault(e => e.UidGuid == uidGuid);
677     var message = "";
678
679     foreach (var modbusAddress in modbusItem.ModbusAddressList)
680     {
681         var address = modbusAddress.Item5;
682
683         if (modbusAddress.Item1)
684             try
685             {
686                 SerialCommunications[index].TotalInformationReceived++;
687                 CalculateNpChart(index);
688                 while (true)
689                 {
690                     try
691                     {
692                         var readCoil = ModbusClients[index].ReadCoils(address, 1);
693                         message =
694                             readCoil.Aggregate(message, (current, b) => current + b.ToString()
695                                 + "\n");
696                     }
697                     catch (IOException)
698                     {
699                         Thread.Sleep(100);
700                         continue;
701                     }
702                     break;
703                 }
704             }
705     }

```

```

703
704         ProtectData(uidGuid, message, ModbusClients[index].IPAddress + "1" +
            modbusAddress.Item5);
705
706         PublishMessage(message, index, uidGuid);
707
708         UpdateGraph(uidGuid,
709             AvailableModbusSerialPorts[
710                 AvailableModbusSerialPorts.Select((val, ind) => new { ind, val })
711                     .First(e => e.val.Uid == uidGuid.ToString())
712                     .ind]
713                 .Name);
714     }
715     catch (CRCCheckFailedException crcCheckFailedException)
716     {
717         if (OutOfControl(index))
718         {
719             var sf = StackTracing.GetFrame(0);
720             LogError(crcCheckFailedException, LogLevel.Critical, sf);
721             MessageBox.Show("CRC Failure. Please check settings and connection",
722                 "CRC Error Check Failure", MessageBoxButton.OK,
723                 MessageBoxIcon.Error);
724             CloseModbusUnexpectedly(uidGuid);
725             ResetCheckBox(AvailableModbusSerialPorts[index]);
726             return;
727         }
728     }
729     if (modbusAddress.Item2)
730     try
731     {
732         SerialCommunications[index].TotalInformationReceived++;
733         CalculateNpChart(index);
734
735         while (true)
736         {
737             try
738             {
739                 var readDiscrete = ModbusClients[index].ReadDiscreteInputs(address,
740                     2);
741                 message =
742                     readDiscrete.Aggregate(message,
743                         (current, b) => current + b.ToString() + "\n");
744             }
745             catch (IOException)
746             {
747                 Thread.Sleep(100);
748                 continue;
749             }
750             break;
751         }
752     }
753     ProtectData(uidGuid, message, ModbusClients[index].IPAddress + "1" +
            modbusAddress.Item5);
754
755     PublishMessage(message, index, uidGuid);
756
757     UpdateGraph(uidGuid,
758         AvailableModbusSerialPorts[

```

```

759             AvailableModbusSerialPorts.Select((val, ind) => new { ind, val })
760                 .First(e => e.val.Uid == uidGuid.ToString())
761                 .ind]
762             .Name);
763     }
764     catch (CRCCheckFailedException crcCheckFailedException)
765     {
766         if (OutOfControl(index))
767         {
768             var sf = StackTracing.GetFrame(0);
769             LogError(crcCheckFailedException, LogLevel.Critical, sf);
770             MessageBox.Show("CRC Failure. Please check settings and connection",
771                 "CRC Error Check Failure", MessageBoxButton.OK,
772                 MessageBoxIcon.Error);
773             CloseModbusUnexpectedly(uidGuid);
774             ResetCheckBox(AvailableModbusSerialPorts[index]);
775             return;
776         }
777     }
778     if (modbusAddress.Item3)
779     try
780     {
781         SerialCommunications[index].TotalInformationReceived++;
782         CalculateNpChart(index);
783
784         while (true)
785         {
786             try
787             {
788                 var readRegister = ModbusClients[index].ReadHoldingRegisters(address,
789                     3);
790                 message =
791                     readRegister.Aggregate(message,
792                         (current, i) => current + i.ToString() + "\n");
793             }
794             catch (IOException)
795             {
796                 Thread.Sleep(100);
797                 continue;
798             }
799             break;
800         }
801
802         ProtectData(uidGuid, message, ModbusClients[index].IPAddress + "1" +
803             modbusAddress.Item5);
804
805         PublishMessage(message, index, uidGuid);
806
807         UpdateGraph(uidGuid,
808             AvailableModbusSerialPorts[
809                 AvailableModbusSerialPorts.Select((val, ind) => new { ind, val })
810                     .First(e => e.val.Uid == uidGuid.ToString())
811                     .ind]
812                 .Name);
813     }
814     catch (CRCCheckFailedException crcCheckFailedException)
815     {
816         if (OutOfControl(index))

```

```

816         {
817             var sf = StackTracing.GetFrame(0);
818             LogError(crcCheckFailedException, LogLevel.Critical, sf);
819             MessageBox.Show("CRC Failure. Please check settings and connection",
820                 "CRC Error Check Failure", MessageBoxButton.OK,
821                 MessageBoxIcon.Error);
822             CloseModbusUnexpectedly(uidGuid);
823             ResetCheckBox(AvailableModbusSerialPorts[index]);
824             return;
825         }
826     }
827     if (modbusAddress.Item4)
828     {
829         try
830         {
831             SerialCommunications[index].TotalInformationReceived++;
832             CalculateNpChart(index);
833             while (true)
834             {
835                 try
836                 {
837                     var readInputRegister = ModbusClients[index].ReadInputRegisters
838                     (address, 4);
839                     message =
840                         readInputRegister.Aggregate(message,
841                             (current, i) => current + i.ToString() + "\n");
842                 }
843                 catch (IOException)
844                 {
845                     Thread.Sleep(100); //attempt to resynchronize
846                     continue;
847                 }
848                 break;
849             }
850         }
851         ProtectData(uidGuid, message, ModbusClients[index].IPAddress + "1" +
852             modbusAddress.Item5);
853         PublishMessage(message, index, uidGuid);
854         UpdateGraph(uidGuid,
855             AvailableModbusSerialPorts[
856                 AvailableModbusSerialPorts.Select((val, ind) => new { ind, val })
857                     .First(e => e.val.Uid == uidGuid.ToString())
858                     .ind]
859                 .Name);
860     }
861     }
862     catch (CRCCheckFailedException crcCheckFailedException)
863     {
864         if (OutOfControl(index))
865         {
866             var sf = StackTracing.GetFrame(0);
867             LogError(crcCheckFailedException, LogLevel.Critical, sf);
868             MessageBox.Show("CRC Failure. Please check settings and connection",
869                 "CRC Error Check Failure", MessageBoxButton.OK,
870                 MessageBoxIcon.Error);
871             CloseModbusUnexpectedly(uidGuid);
872             ResetCheckBox(AvailableModbusSerialPorts[index]);

```

```

872         return;
873     }
874 }
875 }
876 }
877
878 private void ModbusTimerOnTick(object sender, EventArgs eventArgs)
879 {
880     var uidGuid = Guid.Empty;
881     _modbusTimerId.TryGetValue((DispatcherTimer)sender, out uidGuid);
882
883     if (uidGuid == Guid.Empty) return;
884
885     InitializeRead(uidGuid);
886 }
887
888 private void ResetCheckBox(CheckListItem checkListItem)
889 {
890     var index = GetIndex<CheckListItem>(Guid.Parse(checkListItem.Uid));
891
892     this.Dispatcher.Invoke((MethodInvoker)delegate
893     {
894         var checkList = new CheckListItem
895         {
896             Name = checkListItem.Name,
897             Uid = checkListItem.Uid,
898             Content = checkListItem.Content,
899             IsChecked = false
900         };
901
902         if (AvailableSerialPorts.Any(availableSerialPort => checkListItem.Uid ==
903             availableSerialPort.Uid))
904         {
905             AvailableSerialPorts.Remove(AvailableSerialPorts[index]);
906             AvailableSerialPorts.Insert(index, checkList);
907         }
908
909         if (AvailableModbusSerialPorts.Any(
910             availableModbusSerialPort => checkListItem.Uid == availableModbusSerialPort.Uid))
911         {
912             AvailableModbusSerialPorts.Remove(AvailableModbusSerialPorts[index]);
913             AvailableModbusSerialPorts.Insert(index, checkList);
914         }
915     });
916 }
917
918 /// <summary>
919 /// Updates infomration on Statusbar on what system is exeperiencing.
920 /// </summary>
921 /// <param name="sender">
922 /// System Timer Thread Object
923 /// </param>
924 /// <param name="eventArgs">
925 /// Timer Arguments
926 /// </param>
927 private void SystemTimerOnTick(object sender, EventArgs eventArgs)
928 {
929     //Prevents code from running before intialization
930     if (!this.IsInitialized) return;

```



```

931     ResizeSerialSelection();
932     for (var i = 0; i < AvailableSerialPorts.Count; i++)
933     {
934         if (AvailableSerialPorts[i].IsChecked)
935             UpdateGraph(Guid.Parse(AvailableSerialPorts[i].Uid), AvailableSerialPorts
936                 [i].Name);
937         if (AvailableModbusSerialPorts[i].IsChecked)
938             UpdateGraph(Guid.Parse(AvailableSerialPorts[i].Uid), AvailableModbusSerialPorts
939                 [i].Name);
940     }
941
942     for (var i = 0; i < MessagesPerSecond.Length; i++)
943     {
944         MessagesPerSecond[i] = 0.0;
945     }
946
947     private void UpdateGraph(Guid uidGuid, string itemName)
948     {
949         var timeElapsed = DateTime.Now - _previousTime;
950
951         if (timeElapsed < TimeSpan.FromSeconds(1))
952             return; //Only update 1ce per second
953
954         var index = GetIndex<MessageDataHistory>(uidGuid);
955         if (index == -1) return;
956
957         this.Dispatcher.Invoke((MethodInvoker)delegate
958         {
959             if (MessagesSentDataPair[index].Count > 60)
960                 MessagesSentDataPair[index].RemoveAt(0);
961             var timeNow = DateTime.Now.Minute + ":" + DateTime.Now.Second;
962             MessagesPerSecond[index]++;
963
964             if ((Lineseries[index] != null) && ((string)Lineseries[index].Title == itemName))
965             {
966                 var messageDataHistory = new MessageDataHistory
967                 {
968                     KeyPair = new KeyValuePair<string, double>(timeNow,
969                         MessagesPerSecond[index] / timeElapsed.TotalSeconds),
970                     UidGuid = uidGuid
971                 };
972                 MessagesSentDataPair[index].Add(messageDataHistory);
973             }
974             else
975             {
976                 Lineseries[index] = new LineSeries
977                 {
978                     ItemsSource = MessagesSentDataPair[index],
979                     DependentValuePath = "Value",
980                     IndependentValuePath = "Key",
981                     Title = itemName
982                 };
983                 LineChart.Series.Add(Lineseries[index]);
984                 var messageDataHistory = new MessageDataHistory
985                 {
986                     KeyPair = new KeyValuePair<string, double>(timeNow,
987                         MessagesPerSecond[index] / timeElapsed.TotalSeconds),
988                     UidGuid = uidGuid
989                 };

```

```

989         MessagesSentDataPair[index].Add(messageDataHistory);
990     }
991 });
992 }
993
994 ///TODO add IP address Management
995 private void AddModbusTCP_Click(object sender, RoutedEventArgs e)
996 {
997     //
998 }
999
1000 protected internal struct CheckListItem
1001 {
1002     public string Content { get; set; }
1003     public bool IsChecked { get; set; }
1004     public string Name { get; set; }
1005     public string Uid { get; set; }
1006 }
1007
1008 private struct DataBaseInfo
1009 {
1010     internal string Message { get; set; }
1011     internal DateTime TimeStamp { get; set; }
1012     internal string FriendlyName { get; set; }
1013     internal string Channel { get; set; }
1014     internal string Exchange { get; set; }
1015     internal string ServerAddress { get; set; }
1016     internal Guid DeliveryTag { get; set; }
1017     internal string DeviceType { get; set; }
1018 }
1019
1020 protected internal struct MessageDataHistory
1021 {
1022     internal KeyValuePair<string, double> KeyPair { get; set; }
1023     internal Guid UidGuid { get; set; }
1024 }
1025
1026 protected internal struct ModbusControl
1027 {
1028     /// <summary>
1029     /// <para>
1030     /// FunctionCode
1031     /// </para>
1032     /// <para>
1033     /// Address
1034     /// </para>
1035     /// </summary>
1036     public List<Tuple<bool, bool, bool, bool, int>> ModbusAddressList { get; set; }
1037
1038     internal static ObservableCollection<MessageDataHistory> MessagesSentDataPair { get; set; }
1039
1040     internal DispatcherTimer ModbusTimers { get; set; }
1041
1042     internal Guid UidGuid { get; set; }
1043 }
1044 }
1045 }

```